

## **KC3000 Series Power Circuit Board Replacement**

Tools Required:

- Phillips Screwdriver
- Flathead Screwdriver
- Needle Nose Pliers


NOTE: Disconnect the unit from the power source before attempting any repairs

#### Step 1: Remove the power circuit board cover



• On the back of the unit, remove the 4 Phillips screws securing the grated cover over the back of the

• Remove the cover to the circuit board by removing the two Phillips head screws and pressing in the two squeeze clips (one on each side)



Koldfront

Avallon



EdgeStar, 8606 Wall St, Suite 1600, Austin, TX 78754 support.edgestar.com • service@edgestar.com • edgestar.com


\*Warranty service should be performed by an authorized service representative only.




## Step 2: Remove and replace the power circuit board

NOTE: This would be a good time to take a picture of the electrical connections to help put them back in the right place later

• Using needle nose pliers or a flathead screwdriver, release the squeeze clips for the electrical connectors



• After all of the electrical connectors are removed, remove the Phillips screw holding the board in the housing



**EDGESTAR**<sup>®</sup>

Koldfront

Avallon

EdgeStar, 8606 Wall St, Suite 1600, Austin, TX 78754 support.edgestar.com • service@edgestar.com • edgestar.com

\*Warranty service should be performed by an authorized service representative only.



- Line the new circuit board up and install the two Phillips screws securing it to the housing
- Reinstall the electrical connectors

### Step 3: Reinstall the circuit board cover


• Clip the circuit board cover to the housing

NOTE: There are cutouts for the wires to feed through. The wires must be properly fed through these cutouts to allow the cover to properly clip to the housing

• Once the cover is secured to the housing, install the two Phillips screws to attach the housing to the unit



• Reinstall the grated cover over the back of the unit



# **Procedure Complete!**



EdgeStar, 8606 Wall St, Suite 1600, Austin, TX 78754 support.edgestar.com • service@edgestar.com • edgestar.com

\*Warranty service should be performed by an authorized service representative only.