


EDGESTAR[®]

Air Purifier



PUR700W

Owner's Manual

For more information on other great EdgeStar products on the web, go to <http://www.edgestar.com>

Important Safety Information

Improper handling can cause serious damage to the appliance and/or to the user. Please read the following safety information.

Electrical and Safety Requirements—Reduce your risk of fire or electrical shock. Failure to follow these instructions can result in death, fire or electrical shock.

Electrical Safety

- This unit is designed for indoor use only.
- Do not use the unit in extremely humid or wet environments.
- Do not spray water and wet the housing or control panel.
- Do not pull the unit by the cord.
- Always turn the unit off and unplug it from the outlet when cleaning.
- Unplug the unit if it is not going to be used for a long period of time.
- Do not operate the unit with a damaged plug or a loose socket.
- Use only the correct power supply with appropriate amperage.
- If the power cord is damaged, it must be replaced by the manufacturer, a service agent, or qualified technician.
- Do not remove any part of the casing unless instructed by an authorized technician.

General Safety

- This air purifier is not intended to be used by children.
- Children should be supervised to ensure that they do not play with this product.
- Do not allow children to play with the controls or drop any objects into the air outlets or vents.
- Do not place objects or let any person sit on top of the unit.
- Only use in the upright position on a flat, level surface and provide at least 20 inches of clearance from any walls or objects.
- Route the power cord carefully to avoid a tripping hazard.
- This unit is intended for domestic use only. Do not use the air purifier for industrial or commercial use. Any other use may invalidate the warranty.

Electrical products should not be disposed of with household waste. Please contact your local recycling center for more information on how to recycle electronic waste.



Table of Contents

IMPORTANT SAFETY INFORMATION	I
INTRODUCTION	1
PARTS IDENTIFICATION	2
FRONT VIEW	2
BACK VIEW	2
PREPARATIONS	3
INCLUDED FILTERS	4
CONTROL PANEL OVERVIEW	5
REMOTE CONTROL OVERVIEW	6
MAINTENANCE	7
CLEANING THE UNIT	7
CLEANING THE PRE-FILTER	7
CLEANING THE SENSOR	7
PREPARATION FOR STORAGE	7
TROUBLESHOOTING	8
SPECIFICATIONS	9
EDGE STAR LIMITED WARRANTY	10

Introduction

Thank you for purchasing this EdgeStar air purifier. We are glad you chose us. We believe that your purchase of this product opens a relationship between you and EdgeStar. We will provide the customer support needed to nurture that relationship.

This manual contains important information regarding the proper installation, use and maintenance of your air purifier. Following this manual will ensure that your product will work at its peak performance and efficiency.

Please save the original product packaging in case you need to safely transport your air purifier.

For Your Records:

Please write down the model number and serial number below for future reference. Both numbers are located on the ratings label on the back of your unit and are needed to obtain warranty service. You may also want to staple your receipt to this manual as it is the proof of your purchase, and is also needed for service under your warranty.

Model Number: _____

Serial Number: _____


Date of Purchase: _____

To better serve you, please do the following before contacting customer service:


- If you received a damaged product, immediately contact the dealer that sold you the product.
- Read and follow this instruction manual carefully to help you install, use and maintain your air purifier.
- Read the troubleshooting section of this manual as it will help you diagnose and solve common issues.
- Visit us on the web at <http://www.edgestar.com> to register your product, download product guides, additional troubleshooting resources and up-to-date information.
- If you need warranty service, our friendly customer service representatives are available via email at service@edgestar.com or by telephone at **1 (866) 319-5473**.

Parts Identification


Front View




Back View




Preparations



1. Take off the front panel in the direction shown in the figure.



2. Take off the pre-filter by pushing down the two levers connecting it to the unit.



3. Take out the multi-filter and anti-virus filter, both packed in plastic film. Tear off the plastic film.



4. Re-install the filters, pre-filter and the front panel of the unit in the opposite order as shown above.


Included Filters

This unit comes equipped with three (3) separate filters with unique functionalities.

1. **Multi-filter:** Combined 3M HEPA filter with Activated Carbon is designed to remove at least 99.9% of all airborne particles larger than 0.3 microns effectively. The carbon removes odors, chemical vapors, volatile organic compounds, and other gasses.
2. **Anti-Virus Filter:** This filter combats airborne bacteria and viruses in order to reduce the inhalation of harmful contaminants in the air that lead to sickness.
3. **Pre-filter:** Created to block large elements in the air, such as dirt and dust. The grid filter can be washed and replaced after cleaning when needed.

Control Panel Overview

Top View



NOTE: Environments with higher pollutant levels may cause users to replace their filters sooner than 6 months. To order replacement filters visit www.allergyandair.com or call 1-855-302-6628.



POWER BUTTON

Pressing the Power Button once will turn the unit on. By default, the unit will begin to operate in AUTO Mode and the indicator light will illuminate. Pressing this button a second time enables SLEEP Mode. The unit will continue to operate in the previous settings, but will turn off all but the Power Button's indicator light. Pressing this button a third time turns the unit off.



FILTER BUTTON

This air purifier has an internal timer to alert when the filters should be replaced. The indicator light to the left of this button will illuminate after 6 months of run time. Once the new filters are installed hold this button for 5 seconds to reset the timer. This will also turn the indicator light off.



TIMER BUTTON

Pressing the Timer Button enables an automatic shutoff for time frames of four, eight, and twelve hours. The unit will stay on for the allotted time. The indicator lights above this button will indicate the respective set time frame. The Timer can be turned off by pressing this button until no indicator lights are illuminated.



SPEED BUTTON

There are four fan speeds to choose from – Low, Medium, High, and Turbo. Pressing the Speed Button will alternate through these settings. If the unit is in AUTO Mode pressing the Speed Button once will set it to the Low fan speed and turn off AUTO Mode. The indicator lights above this button will indicate the respective fan speed.



AUTO BUTTON

Pressing the Auto Button enables AUTO Mode. The air purifier will select the appropriate fan speed based on the air quality level. Press again to turn off AUTO Mode.



AIR QUALITY INDICATOR LIGHTS


- RED - High level of contaminants.
- BLUE - Moderate level of contaminants.
- GREEN – Low level of contaminants




Remote Control Sensor

Remote Control Overview

The remote control is used to operate most of your air purifier's functions.



NOTE: Be careful not to drop the remote control. Do not place the remote control in a location exposed to direct sunlight.

Button	Function
	Powers the unit on or off. Press once to turn unit on. Press again to turn the indicator lights off for SLEEP Mode. Press again to turn the unit off.
Speed	Selects fan speed which ranges from Low to Turbo.
Timer	Used to enable the Timer.
Auto	Allows the user to initiate AUTO Mode. The air purifier will select the proper fan speed based on the air quality level.

Note: This remote comes equipped with battery. To replace the battery, the user must slide off the backing, and insert a *Lithium 3V Battery, size CR2025.*

Maintenance

Cleaning the unit

Warning: The filters for this unit are not designed to be cleaned or washed. New filters should always be switched for old filters that need to be replaced.

Use a soft dry cloth to wipe the body clean. If necessary, use rubbing alcohol to dampen a cloth to clean the unit.

Use a soft bristle brush to clean between the vents. Do not wash the filters in this unit. The pre-filter can be cleaned with water. See below.

Never use abrasive chemicals, volatile substances, gasoline, detergents, chemically treated cloths, or other cleaning solvents that may damage the cabinet exterior.

Never spray water directly on the unit.

Cleaning the pre-filter



Warning: Never operate the unit without the pre-filter.

To clean the pre-filter, follow the steps below:

- 1) Power off the unit and remove the pre-filter.
- 2) Use a vacuum cleaner or tap the filter lightly to remove loose dust and dirt, then rinse thoroughly under lukewarm running water (below 104°F). You may use a mild soap and water solution if needed. Allow the pre-filter to air dry in a cool and shaded place. Dry thoroughly before reinstalling.

Clean the pre-filter periodically. If the unit is used in a dusty environment you may need to clean it on a weekly basis.

Cleaning the Sensor



Please see the pictures to the left to better depict the following instructions:

- 1) Slightly brush the hatch of the sensor and its surroundings.
- 2) Take off the hatch and wipe the sensor with a cotton stick, shown in the figure below. The cotton stick may be dampened with water, however be sure not to use alcohol. The sensor should be cleaned every two (2) to four (4) weeks to ensure that dust is being detected accurately.



WARNING! RISK OF ELECTRIC SHOCK - These servicing instructions are for use by qualified personnel only. To reduce the risk of electric shock, do not perform any servicing other than that contained in the operating instructions unless you are qualified to do so.

Preparation for Storage

If you are not going to be using the unit for an extended period of time, follow the instructions below before storing your unit:

- 1) Power off the unit, and clean or change the filters.
- 2) Unplug and carefully wind the power cord.
- 3) Store in a cool, dry place.

Troubleshooting

Follow the troubleshooting guide below to resolve common issues.

Issue	Possible Cause	Solution
My air purifier is not functioning at all.	Unit is not receiving power.	Make sure the unit is plugged in to a grounded outlet.
	Insufficient power.	Move the unit to another outlet. Check your circuit breaker. (Refer to the rating label on the back of the unit to determine the Amperage draw).
	The panel is not locked into place.	Try to refit the panel into the designated slots.
	Control panel is disconnected.	If no indicator lights turn on, contact customer service.
My remote control does not work and the indicator light on remote does not turn on.	Batteries not installed.	Install new batteries.
	Bad batteries.	Replace the batteries.
	Batteries installed incorrectly.	Reinstall the batteries correctly.
	A defective remote control.	Contact customer service.
My air purifier is making a loud noise.	The unit is not level.	Make sure the unit is on a level surface.
	A foreign object has jammed the fan.	Remove the object from the fan.
	The packaging on the filter has not been removed.	Remove the filter packaging.
	The pre-filter or multi-filter is very dirty.	Clean the problem filter.
	The floor below the unit is uneven.	Move the unit to a level surface.
My air purifier is making a continuous metallic knocking or pinging sound.	Unit may have been shipped on its side.	Shut off the unit. Let the unit sit on a level surface for at least 24 hours and restart.
	Damaged motor.	Contact customer service.
My air purifier runs for a little while and then it trips the power cord or the circuit breaker.	The air purifier may be plugged into an outlet that cannot supply the correct amount of current.	Contact an electrician if the unit works in a different room or circuit.
The control panel lights blink randomly.	Unit may have a faulty control panel.	Contact customer service.
Speed button does not work.	Unit may be in AUTO mode.	Press AUTO to disable this mode.

Specifications

Description of product	Air Purifier
Model	PUR700W
Voltage/Frequency	AC 120V~60Hz
Input Power	95W
Current	0.8A
Color	White
Timer	4, 8, and 12 hour settings
Dimensions W x H x D	17.75" x 26.75" x 10"
Weight	21 lbs.

EdgeStar Limited Warranty

One (1) Year Parts & Ninety (90) Days Labor

This product is warranted by EdgeStar to be free from defective workmanship and materials, subject to any conditions set forth as follows:

WHAT IS COVERED:

LABOR: For a period of NINETY (90) DAYS from the date of original purchase, labor will be performed free of charge at an authorized EdgeStar repair facility. At its option, EdgeStar will repair the product with new or remanufactured parts, or exchange the defective product with a new, refurbished, or remanufactured product. If a product is replaced, it will carry the remaining warranty of the original product. After the ninety (90) day period, EdgeStar will no longer be responsible for labor charges incurred. All defective products and parts covered by this warranty will be repaired or replaced on a mail-in basis to an EdgeStar authorized repair facility.

PARTS: For a period of ONE (1) YEAR from the date of original purchase, EdgeStar will supply new, rebuilt, or refurbished parts free of charge. EdgeStar may request a defective part be returned in exchange for the replacement part. All replacement parts or products will be new, remanufactured, or refurbished. All products and parts replaced by EdgeStar under warranty service become the property of EdgeStar.

This warranty applies to the original purchaser only, and only covers defects in workmanship experienced during operation of the product under normal service, maintenance, and usage conditions. This warranty applies to the purchase and use of this product in residential settings within the United States of America.

WHAT IS NOT COVERED:

The following limitations apply to the coverage of this warranty. This warranty does not cover:

- Labor charges for installation, setup or training to use the product.
- Shipping damage, and any damage caused by improper packaging for shipment to an authorized service center, and any damaged caused by improper voltage or any other misuse, including abnormal service, handling, or usage.
- Cosmetic damage such as scratches and dents.
- Normal wear and tear on parts or replacement of parts designed to be replaced, e.g. filters, cartridges, batteries.
- Service trips to deliver, pick-up, or repair, install the product, or to instruct in proper usage of the product.
- Damages or operating problems resulting from misuse, abuse, operation outside environmental specifications, uses contrary to instructions provided in the owner's manual, accidents, acts of God, vermin, fire, flood, improper installation, unauthorized service, maintenance negligence, unauthorized installation or modification, or commercial use.
- Labor charges incurred 91 days or more after the date of original purchase.
- The use of EdgeStar products in commercial settings.
- Optional accessories, attachments, and appearance items.
- Products that have been modified to perform outside of specifications without the prior written permission of EdgeStar.
- Products lost in shipment, or theft.
- Products sold AS IS or from an unauthorized reseller.
- Products that have had their serial numbers removed or defaced. Products with serial numbers that have been invalidated.

OBTAINING WARRANTY SERVICE:

If you believe your product is defective, contact EdgeStar Customer Support for troubleshooting assistance and warranty service at 1-866-319-5473. Please have your serial number and proof of purchase available. Once an EdgeStar authorized representative has confirmed that your product is defective and eligible for warranty service, the product must be returned to an EdgeStar repair facility. The purchaser is solely responsible for prepaying all shipping related costs to and from the repair facility. EdgeStar is not responsible for damage resulting from shipper mishandling or improper packaging. Do not return a defective product to the place of purchase. Products received without a return authorization number will be refused.

THIS WARRANTY IS IN LIEU OF ANY OTHER WARRANTY, EXPRESS OR IMPLIED, INCLUDING WITHOUT LIMITATION, ANY WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. TO THE EXTENT ANY IMPLIED WARRANTY IS REQUIRED BY LAW, IT IS LIMITED IN DURATION TO THE EXPRESS WARRANTY PERIOD ABOVE. NEITHER THE MANUFACTURER NOR ITS DISTRIBUTORS SHALL BE LIABLE FOR ANY INCIDENTAL, CONSEQUENTIAL, INDIRECT, SPECIAL, OR PUNITIVE DAMAGES OF ANY NATURE, INCLUDING WITHOUT LIMITATION, LOST REVENUES OR PROFITS, OR ANY OTHER DAMAGE WHETHER BASED IN CONTRACT, TORT, OR OTHERWISE. SOME STATES DO NOT ALLOW THE EXCLUSION OF INCIDENTAL OR CONSEQUENTIAL DAMAGES, SO THE ABOVE EXCLUSION MAY NOT APPLY TO YOU. THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS. YOU MAY HAVE OTHER RIGHTS THAT VARY FROM STATE TO STATE.

EDGESTAR[®]

EdgeStar Products
500 N. Capital of TX Hwy, Bldg 5
Austin, TX 78746

Toll Free: 1-866-319-5473
Web: <http://www.edgestar.com>
E-mail: service@edgestar.com

Register your product, download owner's manuals, access additional troubleshooting resources, and obtain more information on other great EdgeStar products on the web at: **<http://www.edgestar.com>**

Product contents and specifications may change without notice.

Copyright © 2014 Living Direct, Inc. All rights reserved.